

KIMTECH™

Kimtech™ M3 Sterile Pouch Face Mask

Pre Hood Donning Technique



1

Carefully open the protective packaging.



2

While holding the mask through the protective packaging, reach in and separate the head band straps.



3

Pull bands over the head and secure while holding the protective packaging to avoid contaminating the mask.



4

Pinch nose wire into place.



5

Inhale and exhale to check for secure fit.



6

Put hood on over the mask.

